




























- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000067	<ul style="list-style-type: none">  Zawór spustowy  Drain valve 	● 1
	19000107	<ul style="list-style-type: none">  Dioda pomarańczowa  Orange Indication Light 	● 40
	19000108	<ul style="list-style-type: none">  Dioda zielona  Green Indication Light 	● 5
	19000135	<ul style="list-style-type: none">  Fryer Temperature Knob  Pokrętko temperatury – nowy typ 	● 80
	19000266	<ul style="list-style-type: none">  Głowica 400V  Heating head 400V 	● 0

Product image	SKU number	Product name	Available quantity
	19000888	<p>GAŁKI OD ZAWORU SPUSTOWEGO</p> <p>KNOB TO DRAIN VALVE</p> <p>Knob für Entleerungshahn</p>	● 11
	19002560	<p>OPAKOWANIE ZEWNĘTRZNE 75x59x42</p> <p>Outer Packaging 75x59x42</p> <p>Außenverpackung 75x59x42</p>	● 0
	19003159	<p>POKRYWA</p> <p>Deckel</p> <p>cover RCSF-16ETH RCSF-16DTH</p>	● 15
	19009462	<p>Termostat</p> <p>Thermostat</p>	● 311
	19021174	<p>Bezpiecznik termiczny</p> <p>Thermal fuse</p>	● 6
	19023317	<p>Koszyk</p> <p>Basket</p>	● 21

Product image	SKU number	Product name	Available quantity
	19025267	<ul style="list-style-type: none">  Zbiornik dwukomorowy  Fryer body 	<ul style="list-style-type: none"> ● 0
	19028153	<ul style="list-style-type: none">  Plastikowy przycisk RESET  Plastic RESET button 	<ul style="list-style-type: none"> ● 5
	19029303	<ul style="list-style-type: none">  Uchwyt koszyka z mocowaniem do frytkownicy elektrycznej  Basket holder with mounting for electric fryer 	<ul style="list-style-type: none"> ● 2
	19029753	<ul style="list-style-type: none">  Wspornik grzałek kompletny do frytownicy  Complete heater bracket for fryer 	<ul style="list-style-type: none"> ● 0