

























- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.


Product image	SKU number	Product name	Available quantity
	10010129	<ul style="list-style-type: none">  Kosz frytkownicy + uchwyt  Fryer Basket + handle  Korb + Griff 	● 0
	19000059	<ul style="list-style-type: none">  Kabel EU prosta wtyczka  European Plug+Cable 	● 2
	19000063	<ul style="list-style-type: none">  RĄCZKA  GRIFF  HANDLE 	● 85
	19000067	<ul style="list-style-type: none">  Zawór spustowy  Drain valve 	● 2
	19000072	<ul style="list-style-type: none">  Grzałka  Heating Element 	● -2

Product image	SKU number	Product name	Available quantity
	19000077	<p>Wyłącznik bezpieczeństwa</p> <p>Microswitch</p>	● 1
	19000106	<p>Przełącznik 4-pin NOWY TYP</p> <p>4-pin switch NEW TYPE</p>	● 0
	19000107	<p>Dioda pomarańczowa</p> <p>Orange Indication Light</p>	● 36
	19000108	<p>Dioda zielona</p> <p>Green Indication Light</p>	● 3
	19000110	<p>Termostat WYE-190-0010 190C"</p> <p>Thermostat WYE-190-0010 190C"</p>	● 177
	19000112	<p>Nóżka</p> <p>Feet</p>	● 200

Product image	SKU number	Product name	Available quantity
	19000122	<p>🇵🇱 Naklejka panelu przedniego</p> <p>🇬🇧 Panel sticker Silver PVC</p>	● 45
	19000135	<p>🇵🇱 Fryer Temperature Knob</p> <p>🇬🇧 Pokrętło temperatury – nowy typ</p>	● 81
	19000139	<p>🇵🇱 TERMOBEZPIECZNIK WQS-230</p> <p>🇬🇧 THERMOSICHERUNG WQS-230</p> <p>🇩🇪 TEMPERATUR LIMITER</p>	● 0
	19000195	<p>🇵🇱 Sitko-filtr do frytownicy</p> <p>🇬🇧 Strainer-filter for the fryer</p>	● 55
	19000597	<p>🇵🇱 KOSZYK</p> <p>🇬🇧 KORB</p> <p>🇩🇪 BASKET</p>	● 29
	19000874	<p>🇵🇱 TARCZA 200 – NOWY TYP</p> <p>🇬🇧 SAW 200 NEW TYPE</p> <p>🇩🇪 Schild neu 200</p>	● 145

Product image	SKU number	Product name	Available quantity
	19000888	<p>GAŁKI OD ZAWORU SPUSTOWEGO</p> <p>KNOB TO DRAIN VALVE</p> <p>Knob für Entleerungshahn</p>	● 12
	19000889	<p>KOSTKA OD ZASILANIA</p> <p>KERAMIK ISOLATOR</p> <p>BLOCK FOR POWER</p>	● 8
	19000931	<p>Kabel EU zgięta wtyczka 3x1,5mm² 1,6m</p> <p>EU Power cable (bent plug) 3x1,5mm² 1,6m</p>	● 3
	19000946	<p>TERMO-BEZPIECZNIK WQS-240D</p> <p>THERMO-FUSE WQS-240D</p>	● 10
	19001307	<p>GŁOWICA</p> <p>HEIZELEMENT</p> <p>FRYER HEAD</p>	● 0
	19001316	<p>KLIPS</p> <p>CLIP</p> <p>CLIP</p>	● 12
	19001773	<p>UCHWYT DO POKRYWY</p> <p>Griff für die Abdeckung</p> <p>handle for cover für die Friteusen</p>	● 10

Product image	SKU number	Product name	Available quantity
	19001876	<p>🇵🇱 ZBIORNIK</p> <p>🇬🇧 Tank</p> <p>🇩🇪 Becken RCEF 10E</p>	● 0
	19002562	<p>🇵🇱 OPAKOWANIE ZEWNĘTRZNE 53x34x39</p> <p>🇬🇧 Outer Packaging 53x34x39</p> <p>🇩🇪 Außenverpackung 53x34x39</p>	● 0
	19003208	<p>🇵🇱 GRZAŁKA FRYTOWNICY</p> <p>🇬🇧 Heizelement der Friteuse</p> <p>🇩🇪 Heating of the fryer RCES 580H</p>	● 0
	19003209	<p>🇵🇱 TYLNA CZĘŚĆ GŁOWICY</p> <p>🇬🇧 back cover plate</p> <p>🇩🇪 das hintere Teil des Kopfes RCES 580H</p>	● 3
	19003494	<p>🇵🇱 POKRYWKA</p> <p>🇬🇧 COVER</p> <p>🇩🇪 DECKEL RCEF-10EH</p>	● 13
	19008215	<p>🇵🇱 Opakowanie zastępcze 60x40x40</p> <p>🇬🇧 substitute packaging 60x40x40</p>	● 0

Product image	SKU number	Product name	Available quantity
	19014543	 Przelotka kabla  Power cable grommet	 1