

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.





Product image	SKU number	Product name	Available quantity
	10010131	<ul style="list-style-type: none">  Kosz frytkownicy + uchwyt  Fryer Basket + handle  Korb + Griff 	● 0
	19000059	<ul style="list-style-type: none">  Kabel EU prosta wtyczka  European Plug+Cable 	● 2
	19000063	<ul style="list-style-type: none">  RĄCZKA  GRIFF  HANDLE 	● 77
	19000064	<ul style="list-style-type: none">  grzałka do RCEF-13EH  RCEF-13DH HEATING ELEMENT  Heizspirale 	● 20
	19000070	<ul style="list-style-type: none">  Włącznik - 6 pin  Switch 6 pins 	● 0

Product image	SKU number	Product name	Available quantity
	19000077	<p>Wyłącznik bezpieczeństwa</p> <p>Microswitch</p>	● 0
	19000107	<p>Dioda pomarańczowa</p> <p>Orange Indication Light</p>	● 37
	19000108	<p>Dioda zielona</p> <p>Green Indication Light</p>	● 1
	19000110	<p>Termostat WYE-190-0010 190C"</p> <p>Thermostat WYE-190-0010 190C"</p>	● 116
	19000112	<p>Nóżka</p> <p>Feet</p>	● 200
	19000134	RCTF-13DH Cover	● 0

Product image	SKU number	Product name	Available quantity
	19000135	<ul style="list-style-type: none">  Fryer Temperature Knob  Pokrętko temperatury - nowy typ 	● 77
	19000136	<ul style="list-style-type: none">  POKRĘTKO TIMERA  TIMER-KNOB  TIMER KNOB 	● 103
	19000139	<ul style="list-style-type: none">  TERMOBEZPIECZNIK WQS-230  THERMOSICHERUNG WQS-230  TEMPERATUR LIMITER 	● 2
	19000195	<ul style="list-style-type: none">  Sitko-filtr do frytownicy  Strainer-filter for the fryer 	● 53
	19000255	<ul style="list-style-type: none">  Naklejka  Sticker PVC 	● 0
	19000599	<ul style="list-style-type: none">  KOSZYK  KORB  BASKET 	● 16

Product image	SKU number	Product name	Available quantity
	19000874	<p>🇵🇱 TARCZA 200 - NOWY TYP</p> <p>🇬🇧 SAW 200 NEW TYPE</p> <p>🇩🇪 Schild neu 200</p>	● 147
	19000875	<p>🇵🇱 TARCZA 60" - NOWY TYP</p> <p>🇬🇧 SAW 60"" - NEW TYPE</p> <p>🇩🇪 Schild neu 60""</p>	● 60
	19000889	<p>🇵🇱 KOSTKA OD ZASILANIA</p> <p>🇬🇧 KERAMIK ISOLATOR</p> <p>🇩🇪 BLOCK FOR POWER</p>	● 7
	19000931	<p>🇵🇱 Kabel EU zgięta wtyczka 3x1,5mm² 1,6m</p> <p>🇬🇧 EU Power cable (bent plug) 3x1,5mm² 1,6m</p>	● 3
	19000946	<p>🇵🇱 TERMO-BEZPIECZNIK WQS-240D</p> <p>🇬🇧 THERMO-FUSE WQS-240D</p>	● 9
	19001196	<p>🇵🇱 MISA</p> <p>🇬🇧 BECKEN</p> <p>🇩🇪 BOWL</p>	● 1

Product image	SKU number	Product name	Available quantity
	19001316	<ul style="list-style-type: none">  KLIPS  CLIP  CLIP 	● 12
	19001796	<ul style="list-style-type: none">  ELEMENT GRZEWCZY  fryer head  Hezelement RCTF 13EH 	● 4
	19003208	<ul style="list-style-type: none">  GRZAŁKA FRYTOWNICY  Hezelement der Friteuse  Heating of the fryer RCES 580H 	● 0
	19003209	<ul style="list-style-type: none">  TYLNA CZĘŚĆ GŁOWICY  back cover plate  das hintere Teil des Kopfes RCES 580H 	● 2
	19004592	<ul style="list-style-type: none">  OPAKOWANIE ZEWNĘTRZNE 65x51x39  Outer Packaging 65x51x39  Außenverpackung 65x51x39 RCTF-13DH 	● 0
	19008227	<ul style="list-style-type: none">  Opakowanie zastępcze 60x80x40  substitute packaging 60x80x40 	● 106

Product image	SKU number	Product name	Available quantity
	19009063	<p>🇵🇱 Uchwyt pokrywy plastikowy</p> <p>🇬🇧 Plastic lid handle</p>	● 5
	19016096	<p>🇵🇱 Obudowa metalowa</p> <p>🇬🇧 Metal body</p>	● 0
	19024266	<p>🇵🇱 Pokrętło timera</p> <p>🇬🇧 Timmer knob</p>	● 0
	19025727	<p>🇵🇱 Timer 60 z półośką</p> <p>🇬🇧 Timer 60 with a half-axis</p>	● 17