

- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	10010006	<p> RCKF 16DSH</p> <p> Elektrische Kabinettfriteuse 2x16L 380 V / Frytkownica z szafką</p>	● 66
	10010009	<p> RCSF 16ETH</p> <p> 1x16 Friteuse 380 V / Frytkownica</p>	● 0
	10010023	<p> RCEF 16EH</p> <p> 1x16 Friteuse / Frytkownica</p>	● 0
	10010028	<p> Frytkownica elektryczna 2x 16L</p> <p> 2x16l litre deep fat chip fryer</p> <p> Elektro Fritteuse 2x16l</p>	● 67
	10010029	<p> RCEF 16DH</p> <p> 2x16 Friteuse / Frytkownica</p>	● 0

Product image	SKU number	Product name	Available quantity
	1001142	<p>🇵🇱 FRYTOWNICA 16L</p> <p>🇬🇧 Deep Fryer 16L</p> <p>🇩🇪 Friteuse 16L</p>	● 162