




















- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	1900111	<ul style="list-style-type: none"> Termostat regulowany 300C 250V 16A adjustable thermostat 300C 250V 16A regulierbarer Thermostat 300C 250V 16A 	0
	19001799	<ul style="list-style-type: none"> OBUDOWA GÓRNA upper housing das Obergehäuse do RCWM-1K 	0
	19002335	<ul style="list-style-type: none"> TERMOSTAT 300C Z POKRĘTLEM BAZA thermostat 300C with knob 	2
	19002357	<ul style="list-style-type: none"> Dioda zielona green indicator RCNK-4,RCNK-6,RCNK-4-GN,RCWM-1500-S,RCWS-30,RCWS-60,RCWM-1300-R,RCWM-2600-R,RCWM-2000-E,RCKG-2200-G,RCKG-2200,RCKG-3600-G,RCWM-1500-H,RCWM-4000-E,RCEC-3000-R,RCEG-55,RCEG-75,RCEC-3000-E,RCEC-6000-E,RCEF-10EY-ECD, RCEF-10DY- 	45
	19002358	<ul style="list-style-type: none"> DIODA POMARAŃCZOWA orange indicator RCNK-4,RCNK-6,RCNK-4-GN,RCWM-1500-S,RCWS-30,RCWS-60,RCWM-1300-R,RCWM-2600-R,RCWM-2000-E,RCKG-2200-G,RCKG-2200,RCKG-3600-G,RCWM-1500-H,RCWM-4000-E,RCEC-3000-R,RCEG-55,RCEG-75,RCEC-3000-E,RCEC-6000-E,RCEF-10EY-ECD, RCEF 	39
	19002359	<ul style="list-style-type: none"> TIMER 15 MIN. Z POKRĘTLEM BAZA 15 mins timer with knob 	1
	19002623	<ul style="list-style-type: none"> OPAKOWANIE ZEWNĘTRZNE 70x54x34 Outer Packaging 70x54x34 Außenverpackung 70x54x34 	0
	19002698	<ul style="list-style-type: none"> GRZÁŁKA HEATING ELEMENT HEIZSPIRALE RCWM-2000-E 	1
	19002797	<ul style="list-style-type: none"> Oslona kabla Cabel Cover Kabelschutz RCWM-1500-H 	2
	19003008	<ul style="list-style-type: none"> RAČZKA DO GOFROWNICY Handle Griff RCWM-2000-E 	5
	19003048	<ul style="list-style-type: none"> POKRĘTŁO TIMERA Timer-Knob 	9
	19003049	<ul style="list-style-type: none"> TIMER 15 MIN. Timer 15 Minuten 	0
	19003236	<ul style="list-style-type: none"> OBUDOWA URZĄDZENIA GEHÁUSE HOUSING RCWM-4000-E 	0
	19003484	<ul style="list-style-type: none"> NAKLEJKA Sticker Aufkleber RCWM-4000-E 	0
	19003491	<ul style="list-style-type: none"> EMALIA WODNA Wasseremaille watherenamel RCKG-2200 	0
	19003495	<ul style="list-style-type: none"> RYNIENKA Rinne through RCWM-4000-E 	17
	19003496	<ul style="list-style-type: none"> RYNIENKA TYŁ Rinne hinten through back RCWM-4000-E 	11
	19003694	<ul style="list-style-type: none"> TERMOSTAT THERMOSTAT THERMOSTAT RCKG-3600-G 	18

Product image	SKU number	Product name	Available quantity
	19003723	<ul style="list-style-type: none"> Płyta dolna Bottom board 	0
	19003953	<ul style="list-style-type: none"> PLYTA GÓRNA OBERE PLATINE UPPER BOARD RCWM-2000-E 	0
	19004887	<ul style="list-style-type: none"> PLASTIKOWY UCHWYT Plastikhalterung plastic handle RCKG-3600-G 	1
	19008227	<ul style="list-style-type: none"> Opakowanie zastępcze 60x80x40 substitute packaging 60x80x40 	118
	19025197	<ul style="list-style-type: none"> Zestaw płyt grzewczych Set of heating plates 	4