

- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000111	<ul style="list-style-type: none"> Termostat regulowany 300C 250V 16A adjustable thermostat 300C 250V 16A regulierbarer Thermostat 300C 250V 16A 	0
	19000135	<ul style="list-style-type: none"> Fryer Temperature Knob Pokrętko temperatury - nowy typ 	77
	19000870	<ul style="list-style-type: none"> TARCA 300 - NOWY TYP SAW 300 - NEW TYPE Scheibe MSW-ROLLER-900Y 	104
	19001719	<ul style="list-style-type: none"> RĄCZKA Griff handle DO RCMW-1200K 	8
	19002335	<ul style="list-style-type: none"> TERMOSTAT 300C Z POKRĘTŁEM BAZA thermostat 300C with knob 	2
	19002357	<ul style="list-style-type: none"> Dioda zielona green indicator RCNK-4,RCNK-6,RCNK-4-GN,RCWM-1500-S,RCWS-30,RCWS-60,RCWM-1300-R,RCWM-2600-R,RCWM-2000-E,RCKG-2200-G,RCKG-2200,RCKG-3600-G,RCWM-1500-H,RCWM-4000-E,RCEC-3000-R,RCEG-55,RCEG-75,RCEC-3000-E,RCEC-6000-E,RCEF-10EY-ECD,RCEF-10DY- 	43
	19002358	<ul style="list-style-type: none"> DIODA POMARAŃCZOWA orange indicator RCNK-4,RCNK-6,RCNK-4-GN,RCWM-1500-S,RCWS-30,RCWS-60,RCWM-1300-R,RCWM-2600-R,RCWM-2000-E,RCKG-2200-G,RCKG-2200,RCKG-3600-G,RCWM-1500-H,RCWM-4000-E,RCEC-3000-R,RCEG-55,RCEG-75,RCEC-3000-E,RCEC-6000-E,RCEF-10EY-ECD,RCEF 	39
	19002359	<ul style="list-style-type: none"> TIMER 15 MIN. Z POKRĘTŁEM BAZA 15 mins timer with knob 	1
	19002624	<ul style="list-style-type: none"> OPAKOWANIE ZEWNĘTRZNE 56x44x32 Outer Packaging 56x44x32 Außenverpackung 56x44x32 	0
	19002697	<ul style="list-style-type: none"> GRZĄŁKA HEATING ELEMENT HEIZSPIRALE RCWM-1300-R, RCWM-2600-R 	2
	19002987	<ul style="list-style-type: none"> Obudowa górna Oberes Gehäuse upper casing RCWM-2600-R, RCWM-1300-R 	0
	19002988	<ul style="list-style-type: none"> Płyta robocza - góra Arbeitsplatte oben Workplate top 	9
	19003048	<ul style="list-style-type: none"> POKRĘTŁO TIMERA Timer-Knob 	9
	19003049	<ul style="list-style-type: none"> TIMER 15 MIN. Timer 15 Minuten 	0
	19003126	<ul style="list-style-type: none"> PLYTA ROBOCZA DÓŁ Arbeitsplatte unten lower working plate RCWM-2600-R 	9
	19003694	<ul style="list-style-type: none"> TERMOSTAT THERMOSTAT THERMOSTAT RCKG-3600-G 	13
	19008216	<ul style="list-style-type: none"> Opakowanie zastępcze 60x60x40 substitute packaging 60x60x40 	115