














- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19004739	<ul style="list-style-type: none">  NÓŻKA  FUß  FOOT RCLK-S600 	● 7
	19018937	<ul style="list-style-type: none">  Półka metalowa  Metal shelf 	● 0
	19018938	<ul style="list-style-type: none">  Prowadnica półki metalowa  Metal shelf guide 	● 0
	19026297	<ul style="list-style-type: none">  Uszczelka drzwi  Door gasket 	● 0