


- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>10010223</b>	<ul style="list-style-type: none"> <li> ZESTAW ŁYŻKA+KUBEK</li> <li> shovel+cup</li> <li> Löffel+Becher</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19000062</b>	<ul style="list-style-type: none"> <li> Włącznik 4 pin - nowy typ (większy)</li> <li> Power Switch 4 pins- new type (bigger size)</li> </ul>	<span style="color: green;">●</span> <b>203</b>
	<b>19000153</b>	<ul style="list-style-type: none"> <li> Grzałka 1000W</li> <li> Heater 1000 W</li> </ul>	<span style="color: red;">●</span> <b>-1</b>
	<b>19000206</b>	<ul style="list-style-type: none"> <li> Garnek wtyczka 3 PIN żeńska (STARY TYP)</li> <li> Pot 3 PIN female plug (OLD TYPE)</li> </ul>	<span style="color: red;">●</span> <b>-23</b>
	<b>19000207</b>	<ul style="list-style-type: none"> <li> TERMOSTAT 230C RCPS</li> <li> RCPR</li> <li> RCPW-16E</li> </ul>	<span style="color: green;">●</span> <b>64</b>

Product image	SKU number	Product name	Available quantity
	<b>19000398</b>	<p>🇵🇱 MIESZADŁO</p> <p>🇬🇧 Popcorn Stirrer</p> <p>🇩🇪 Rührstab for RCPS-16E, RCPR-16E, RCPW-16E</p>	● 0
	<b>19000604</b>	<p>🇵🇱 Żarówka E27 60W</p> <p>🇬🇧 Bulb E27 60W</p>	● 10
	<b>19001291</b>	<p>🇵🇱 Szyba tylna 45x53 cm</p> <p>🇬🇧 Back glass 45x53 cm (for S04)</p>	● 7
	<b>19001292</b>	<p>🇵🇱 Szyba boczna 31x53 cm</p> <p>🇬🇧 Side glass 31x53 cm (for S04)</p>	● 2
	<b>19001432</b>	<p>🇵🇱 WSPORNIK BOCZNY</p> <p>🇬🇧 Seitenkonsole</p> <p>🇩🇪 Side bracket DO RCPR-16E</p>	● 0
	<b>19001693</b>	<p>🇵🇱 Uszczelka</p> <p>🇬🇧 Rubber seal</p>	● 0

Product image	SKU number	Product name	Available quantity
	<b>19001792</b>	<p>🇵🇱 PVC DO SZYBY TYLNEJ</p> <p>🇬🇧 pvc for back glas</p> <p>🇩🇪 PVC für Hinterscheibe do RCPS-16E, RCPR-16E, RCPW-16E</p>	● <b>3</b>
	<b>19002021</b>	<p>🇵🇱 GNIAZDO BEZPIECZNIKOWE</p> <p>🇬🇧 fuse base</p> <p>🇩🇪 Sicherungssockel RCPS-16E</p>	● <b>0</b>
	<b>19002235</b>	<p>🇵🇱 DRZWI SZKLANE LEWE</p> <p>🇬🇧 Glastür links</p> <p>🇩🇪 glass door left RCPR-16E</p>	● <b>0</b>
	<b>19002236</b>	<p>🇵🇱 DRZWI SZKLANE PRAWA</p> <p>🇬🇧 Glastür</p> <p>🇩🇪 glass door right RCPR-16E</p>	● <b>0</b>
	<b>19003994</b>	<p>🇵🇱 DASZEK</p> <p>🇬🇧 DACH</p> <p>🇩🇪 HOOD RCPW-16.1</p>	● <b>4</b>
	<b>19005513</b>	<p>🇵🇱 ZAWLECZKA METALOWA</p> <p>🇬🇧 metal pin</p> <p>🇩🇪 Metallsplint</p>	● <b>0</b>

Product image	SKU number	Product name	Available quantity
	<b>19006654</b>	<ul style="list-style-type: none"> <li>Opakowanie zewnętrzne 46x60x82</li> <li>outside packaging 46x60x82</li> <li>Außenverpackung 46x60x82</li> </ul>	● 0
	<b>19008231</b>	<ul style="list-style-type: none"> <li>Opakowanie zastępcze 60x60x80</li> <li>substitute packaging 60x60x80</li> </ul>	● 112
	<b>19017390</b>	<ul style="list-style-type: none"> <li>Drzwi szklane 36.5x21.5 cm [NOWY TYP]</li> <li>Glass door 36.5x21.5 cm [NEW TYPE] (for S04)</li> </ul>	● 65
	<b>19027401</b>	<ul style="list-style-type: none"> <li>Dolna płyta maszyny do popcornu</li> <li>Bottom plate for popcorn machine</li> </ul>	● 0
	<b>19029000</b>	<ul style="list-style-type: none"> <li>Garnek wtyczka 3 PIN męska (NOWY TYP)</li> <li>Pot 3 PIN male plug (NEW TYPE)</li> </ul>	● 12
	<b>19029166</b>	<ul style="list-style-type: none"> <li>Gniazdo 3 PIN zasilania garnka - żeńskie</li> <li>Gniazdo 3 PIN zasilania garnka - żeńskie</li> </ul>	● 62

Product image	SKU number	Product name	Available quantity
	<b>19029167</b>	<p>🇵🇱 Wtyczka 3 PIN zasilania garnka - męska</p> <p>🇬🇧 3-PIN Plug for pot power - male</p>	● <b>67</b>
	<b>19029168</b>	<p>🇵🇱 Gniazdo 3 PIN zasilania garnka - męskie</p> <p>🇬🇧 3-PIN Socket for pot power - male</p>	● <b>46</b>
	<b>19029169</b>	<p>🇵🇱 Wtyczka 3 PIN zasilania garnka - żeńska</p> <p>🇬🇧 3-PIN Plug for pot power - female</p>	● <b>44</b>