

















- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19004322	<ul style="list-style-type: none">  Termobezpiecznik resetowalny KSD306X 250V 20A 140C  thermal fuse-reset KSD306X 250V 20A 140C  Thermosicherung mit Reset KSD306X 250V 20A 140C 	● 1
	19004397	<ul style="list-style-type: none">  KRAN  WASSERHAHN  TAP RCWK 10A 	● 0
	19004399	<ul style="list-style-type: none">  OCIEKACZ  TROPFFILTER  Drainage board RCWK 10A 	● 10
	19004400	<ul style="list-style-type: none">  CHWYT  GRIFF  Handle RCWK 10A 	● 10

Product image	SKU number	Product name	Available quantity
	19004515	<p>🇵🇱 SPÓD OBUDOWY</p> <p>🇬🇧 Boden des Gehäuses</p> <p>🇩🇪 bottom of the housing RCWK 26A</p>	● 10
	19008394	<p>🇵🇱 Opakowanie zewnętrzne 35x36x52</p> <p>🇬🇧 Outer packaging 35x36x52</p>	● 13
	19015996	<p>🇵🇱 Gałka termostatu</p> <p>🇬🇧 Thermostat knob</p>	● 0