




- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19004417	<ul style="list-style-type: none">  SZYBA BOCZNA  SEITENSCHIEBE  SIDE GLASS RCNW-1 	● 8
	19004418	<ul style="list-style-type: none">  SZYBA TYLNA  HINTERE SCHEIBE  BACK GLASS RCNW-1 	● 12
	19004480	<ul style="list-style-type: none">  ŻARÓWKA  GLÜHBIRNE  BULB RCNW-1 	● 13
	19004505	<ul style="list-style-type: none">  ZESTAW NAKLEJEK  Sticker Set  Aufkleber Set RCNW-1 	● 0
	19004796	<ul style="list-style-type: none">  MAGNES  MAGNET  MAGNET RCNW-1 	● 1

Product image	SKU number	Product name	Available quantity
	19005044	<ul style="list-style-type: none">  ŁOPATKA  blade  Flügel RCNW-1 	● 0
	19006400	<ul style="list-style-type: none">  Szyba przednia 21cmx36cm  front glass 21cmx36cm  vordere Scheibe 21cmx36cm 	● 5
	19008133	<ul style="list-style-type: none">  Opakowanie zewnętrzne 48x40x67  Outer packaging 48x40x67 	● 0
	19008165	<ul style="list-style-type: none">  Opakowanie zewnętrzne 40x48x67  Outer packaging 40x48x67 	● 0
	19012342	<ul style="list-style-type: none">  Listwa mocująca górna szybę  The upper glass mounting strip 	● 1
	19012417	<ul style="list-style-type: none">  Pokrywa z uchwytem  Cover with handle 	● 0

Product image	SKU number	Product name	Available quantity
	19020769	 Kłapa metalowa  Door	● 0
	19029800	 Płyta z kratką do podgrzewacza do nachos  Plate with grid for nacho warmer	● 0
	19030151	 Przełącznik zasilania  Power switch	● 0