













- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
 GASTROPARTS	19001752	<ul style="list-style-type: none">  Przełącznik zielony 4-pin  green switch 4-pin  grüner Umschalter 4-pin 	● 54
	19007844	<ul style="list-style-type: none">  Opakowanie zewnętrzne 38x145x30  outer packaging 38x145x30 	● 18
	19008530	<ul style="list-style-type: none">  Obudowa metalowa  Metal housing 	● 14
	19008531	<ul style="list-style-type: none">  Pokrywa metalowa prawa  Right metal lid 	● 0
	19008532	<ul style="list-style-type: none">  Pokrywa metalowa lewa  Left metal lid 	● 1

Product image	SKU number	Product name	Available quantity
	19008533	<p>  Zawias metalowy  Metal hinge </p>	<p>● 0</p>
	19008636	<p>  Nóżka wkręcana  Screwable foot </p>	<p>● 28</p>
	19008912	<p>  Obudowa bok prawy  Housing right side </p>	<p>● 0</p>
	19025552	<p>  Przełącznik zielony 4-pin (NOWY TYP - nowa konstrukcja wewnętrzna)  Green switch 4-pin (NEW TYPE- new internal construction) </p>	<p>● 120</p>