





- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	10010223	<ul style="list-style-type: none">  ZESTAW ŁYŻKA+KUBEK  shovel+cup  Löffel+Becher 	● 0
	19000206	<ul style="list-style-type: none">  Garnek wtyczka 3 PIN żeńska (STARY TYP)  Pot 3 PIN female plug (OLD TYPE) 	● 12
	19000604	<ul style="list-style-type: none">  Żarówka E27 60W  Bulb E27 60W 	● 4
	19001292	<ul style="list-style-type: none">  Szyba boczna 31x53 cm  Side glass 31x53 cm (for S04) 	● 0
	19002032	<ul style="list-style-type: none">  ELEMENT MIESZADŁA  Teil vom Rührarm  stirrer element RCPS-16E 	● 52

Product image	SKU number	Product name	Available quantity
	19002683	<p>🇵🇱 Szuflada 20x17 cm</p> <p>🇬🇧 Drawer 20x17 cm (for S04)</p>	● 0
	19002802	<p>🇵🇱 Pokrywka garnka</p> <p>🇬🇧 Cover pot</p> <p>🇩🇪 Topfdeckel RCPR-16E</p>	● 0
	19002979	<p>🇵🇱 Uchwyt drzwiczek</p> <p>🇬🇧 Tür-Griff</p> <p>🇩🇪 Door handle</p>	● 122
	19013912	<p>🇵🇱 Łopatkka plastikowa</p> <p>🇬🇧 Plastic spatula</p>	● 1
	19014304	<p>🇵🇱 Elementy mieszadła</p> <p>🇬🇧 Agitator elements</p>	● 50
	19016852	<p>🇵🇱 Daszek górny</p> <p>🇬🇧 Top roof</p>	● 0

Product image	SKU number	Product name	Available quantity
	19017040	<p>🇵🇱 Gniazdo żarówki</p> <p>🇬🇧 Lamp holder</p>	● 3
	19024827	<p>🇵🇱 Kabel zasilający</p> <p>🇬🇧 Power cable</p>	● 3
	19025176	<p>🇵🇱 Drzwi szklane lewe z zawiasami</p> <p>🇬🇧 Left glass door with hinges</p>	● 0
	19025177	<p>🇵🇱 Drzwi szklane prawe z zawiasami</p> <p>🇬🇧 Right glass door with hinges</p>	● 0
	19025681	<p>🇵🇱 Sprężyna uchwyty garnka</p> <p>🇬🇧 Pot handle spring</p>	● 1
	19026910	<p>🇵🇱 Szyba tylna z naklejką</p> <p>🇬🇧 back glass with a sticker</p>	● 1

Product image	SKU number	Product name	Available quantity
	19027665	<p>🇵🇱 Osłona dolna do maszyny do popcornu</p> <p>🇬🇧 Popcorn machine bottom panel</p>	● 0
	19028453	<p>🇵🇱 Wspornik daszku przedni</p> <p>🇬🇧 Front roof support</p>	● 1
	19029000	<p>🇵🇱 Garnek wtyczka 3 PIN męska (NOWY TYP)</p> <p>🇬🇧 Pot 3 PIN male plug (NEW TYPE)</p>	● 23
	19029070	<p>🇵🇱 Wspornik daszku boczny</p> <p>🇬🇧 Side roof support</p>	● 0
	19029166	<p>🇵🇱 Gniazdo 3 PIN zasilania garnka - żeńskie</p> <p>🇬🇧 Gniazdo 3 PIN zasilania garnka - żeńskie</p>	● 64
	19029167	<p>🇵🇱 Wtyczka 3 PIN zasilania garnka - męska</p> <p>🇬🇧 3-PIN Plug for pot power-male</p>	● 68

Product image	SKU number	Product name	Available quantity
	19029168	<p>🇵🇱 Gniazdo 3 PIN zasilania garnka - męskie</p> <p>🇬🇧 3-PIN Socket for pot power - male</p>	● 46
	19029169	<p>🇵🇱 Wtyczka 3 PIN zasilania garnka - żeńska</p> <p>🇬🇧 3-PIN Plug for pot power- female</p>	● 45
	19029736	<p>🇵🇱 Metalowy panel przedni maszyny do popcornu</p> <p>🇬🇧 Metal front panel of the popcorn machine</p>	● 0