expondo



SKU 10011147 Spare parts


List of available spare parts and related products

15/11/2026

Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.

The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	**10010129**	Kosz frytkownicy + uchwyt Fryer Basket + handle Korb + Griff	**150**
	**19000110**	Termostat WYE-190-0010 190C" Thermostat WYE-190-0010 190C"	**0**
	**19000563**	BOWL FOR RCTF-10EH, RCTF-10DH miska	**0**
	**19000597**	KOSZYK KORB BASKET	**28**
	**19000895**	GRZAŁKA RCTF 10EH DH HEATING ELEMENT	**-2**

Product image	SKU number	Product name	Available quantity
	**19001752**	Przełącznik zielony 4-pin green switch 4-pin grüner Umschalter 4-pin	**0**
	**19002435**	POKRYWA COVER DECKEL RCTF-10DH	**2**
	**19007833**	Opakowanie zewnętrzne 64x51x35 outer packaging 64x51x35	**0**
	**19009281**	Termobezpiecznik Thermal fuse	**5**
	**19014713**	Głowica grzewcza kompletna Complete heating head	**2**
	**19030665**	Głowica grzewcza kompletna Complete heating head	**0**
	**19030688**	Pokrętło timera Timer knob	**0**