




























- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19018555	<ul style="list-style-type: none">  Silnik HL-B20 750W kompletny  HL-B20 750W motor complete 	● 1
	19019297	<ul style="list-style-type: none">  Lewy zacisk zabezpieczający miski  Left bowl securing clamp 	● 1
	19019610	<ul style="list-style-type: none">  Kompletny silnik 750 W z obudową i przekładnią  Complete 750 W motor with housing and gearbox 	● 0
	19020087	<ul style="list-style-type: none">  Trzepaczka do miksera  Whisk for the mikser 	● 0
	19023652	<ul style="list-style-type: none">  Podstawa dolna  Bottom base 	● 1

Product image	SKU number	Product name	Available quantity
	19023838	<p> Plastikowa osłona (kompletna)</p> <p> Plastic cover (complete)</p>	● 0
	19023936	<p> Misa 20l</p> <p> Bowl 20l</p>	● 2
	19024611	<p> Gumowa podkładka przednia</p> <p> Rubber front pad</p>	● 9
	19024612	<p> Gumowa podkładka tylna</p> <p> Rubber back pad</p>	● 1