





- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19013158	<ul style="list-style-type: none">  Pompa kompletna z pokrywą  Complete pump with cover 	● 0
	19017622	<ul style="list-style-type: none">  Grzałka  Heating ring 	● 2
	19017623	<ul style="list-style-type: none">  Bezpiecznik resetowalny 130 stopni  Resettable fuse 130 degree 	● 1
	19026556	<ul style="list-style-type: none">  Zbiornik ze stali nierdzewnej 4,5 L do podgrzewacza do czekolady  Stainless steel container 4,5 L for chocolate warmer 	● 0
	19026875	<ul style="list-style-type: none">  Tłok pompy do podgrzewacza do czekolady  Pump piston for chocolate warmer 	● 0

Product image	SKU number	Product name	Available quantity
	19027658	<p>🇵🇱 Termostat</p> <p>🇬🇧 Thermostat</p>	● 0
	19028854	<p>🇵🇱 Gumowa nóżka</p> <p>🇬🇧 Rubber foot</p>	● 8
	19029006	<p>🇵🇱 Grzałka wylewki pompki</p> <p>🇬🇧 Pump spout heater</p>	● 0
	19030061	<p>🇵🇱 Zestaw wkładów graficznych</p> <p>🇬🇧 Set of graphic inserts</p>	● 0