
















- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19012500	<ul style="list-style-type: none">  Termobezpiecznik-250V-15A  Thermal fuse-250V-15A 	● 1
	19014114	<ul style="list-style-type: none">  Rączka plastikowa  Plastic handle 	● 6
	19016328	<ul style="list-style-type: none">  Garnek wewnętrzny 10L  10L inner pot 	● -1
	19017732	<ul style="list-style-type: none">  Termostat  Thermostat 	● 6
	19021798	<ul style="list-style-type: none">  Kompletny biały garnek  Complete White pot 	● 1

Product image	SKU number	Product name	Available quantity
	19029977	 Pokrywa garnka do gotowania ryżu  Rice cooker lid	 0