






- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000143	<ul style="list-style-type: none"> 🇵🇱 WŁĄCZNIK 4 PIN (NOWY TYP, MNIEJSZY) 🇬🇧 EIN- 🇩🇪 AUSSCHALTER 	● 162
	19000154	<ul style="list-style-type: none"> 🇵🇱 TERMOSTAT 230C 🇬🇧 Thermostat 230 C RCZC-1200E, RCZK-120 	● 18
	19000578	<ul style="list-style-type: none"> 🇵🇱 POWER CORD FOR RCHG-5E 🇬🇧 7E kabel zasilający 🇩🇪 Netzkabel 	● 5
	19023006	<ul style="list-style-type: none"> 🇵🇱 Śróbka głowicy 🇬🇧 Head screw 	● 1
	19023086	<ul style="list-style-type: none"> 🇵🇱 Góra głowicy 🇬🇧 Head top 	● 0

Product image	SKU number	Product name	Available quantity
	19026732	<p>  Głowica obrotowa do maszyny do waty cukrowej  Spinner head for candy floss machine </p>	<p>● 2</p>
	19028662	<p>  Wrzeciono NOWY TYP  Spindle for candy floss machine NEW TYPE </p>	<p>● 2</p>