










- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19018023</b>	<ul style="list-style-type: none"> <li> Timer 120 minut</li> <li> Timer 120 minutes</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19024039</b>	<ul style="list-style-type: none"> <li> Uszczelka drzwi</li> <li> Door seal</li> </ul>	<span style="color: green;">●</span> <b>1</b>
	<b>19024728</b>	<ul style="list-style-type: none"> <li> Pokrętło timera</li> <li> Timer knob</li> </ul>	<span style="color: red;">●</span> <b>0</b>