










- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19014570	🇵🇱 Termometr 500 C 🇬🇧 Thermometer 500 C	● 2
	19014574	🇵🇱 Włącznik kołyskowy 🇬🇧 Rocker switch	● 1
	19014585	🇵🇱 Pokrętko 🇬🇧 Knob	● 3
	19014589	🇵🇱 Lampa 🇬🇧 Lamp	● 0
	19014591	🇵🇱 Przełącznik główny 🇬🇧 Main switch	● 1

Product image	SKU number	Product name	Available quantity
	19018814	<p>🇵🇱 Termostat 45 - 455 °C</p> <p>🇬🇧 Thermostat 45 - 455 °C</p>	● 1
	19019604	<p>🇵🇱 Grzałka 1200W</p> <p>🇬🇧 Heater 1200W</p>	● 0
	19023861	<p>🇵🇱 Kamienna Płyta [99 x 33 cm]</p> <p>🇬🇧 Stone plate [99 x 33 cm]</p>	● 2
	19024283	<p>🇵🇱 Drzwi kompletne</p> <p>🇬🇧 Complete door</p>	● 0