

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000062	<ul style="list-style-type: none">  Włącznik 4 pin - nowy typ (większy)  Power Switch 4 pins- new type (bigger size) 	● 202
	19026119	<ul style="list-style-type: none">  Szyba tylnych drzwiczek  Rear door glass 	● 0
	19026720	<ul style="list-style-type: none">  Uchwyt drzwiczek  Door handle 	● 1
	19029528	<ul style="list-style-type: none">  Szyba boczna  Side glass 	● 0
	19029529	<ul style="list-style-type: none">  Włącznik czerwony z podświetleniem  Red on  off switch with backlight 	● 0

Product image	SKU number	Product name	Available quantity
	19030195	<p> Listwa mocowania półki do witryny grzewczej</p> <p> Grid shelf support bar for food display counter</p>	<p>● 0</p>