

















- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19005451	<ul style="list-style-type: none">  Grzałka płaska - górna 670W  Upper flat heater 670W 	● 5
	19023284	<ul style="list-style-type: none">  Metalowa tacka  Metal tray 	● 0
	19024703	<ul style="list-style-type: none">  Płyta grzewcza górna  Upper heating plate 	● 0
	19024704	<ul style="list-style-type: none">  Płyta grzewcza dolna  Bottom heating plate 	● 2
	19025368	<ul style="list-style-type: none">  Uchwyt  Handle 	● 10

Product image	SKU number	Product name	Available quantity
	19027741	<p>🇵🇱 Śruba imbusowa do mocowania uchwyty</p> <p>🇬🇧 Allen screw for handle</p>	● 0