

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
 GASTROPARTS	19001752	<ul style="list-style-type: none">  Przełącznik zielony 4-pin  green switch 4-pin  grüner Umschalter 4-pin 	● 63
	19017038	<ul style="list-style-type: none">  Promiennik podczerwieni 350W STARY TYP  Infrared heater 350 W OLD TYPE 	● 36
	19017863	<ul style="list-style-type: none">  Pokrętło timera  Timer knob 	● 3
	19025552	<ul style="list-style-type: none">  Przełącznik zielony 4-pin (NOWY TYP - nowa konstrukcja wewnętrzna)  Green switch 4-pin (NEW TYPE- new internal construction) 	● 123
	19027999	<ul style="list-style-type: none">  Promiennik podczerwieni 115V 500W NOWY TYP  Infrared heater 115V 500W NEW TYPE 	● 0

Product image	SKU number	Product name	Available quantity
	19029029	 Gniazdo promiennika do grilla na podczerwień  Infrared grill heater socket	● 0
	19029932	 Timer 30" SE-030 do grilla  Timer 30" SE-030 for grill	● 0