

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000077	<ul style="list-style-type: none">  Wyłącznik bezpieczeństwa  Microswitch 	● 0
	19001752	<ul style="list-style-type: none">  Przełącznik zielony 4-pin  green switch 4-pin  grüner Umschalter 4-pin 	● 45
	19026967	<ul style="list-style-type: none">  Grzałka 230V 1700W  Heater 230V 1700W 	● 0
	19027465	<ul style="list-style-type: none">  Głowica grzewcza kompletna 400V  Complete heating head 400V 	● 1
	19027610	<ul style="list-style-type: none">  Stycznik  Contactor 	● 0

Product image	SKU number	Product name	Available quantity
	19029841	<p data-bbox="654 257 1117 336">🇵🇱 Kosz kompletny 25x23x12cm do frytownicy</p> <p data-bbox="654 347 1117 425">🇬🇧 Complete basket 25x23x12 cm for electric fryer</p>	<p data-bbox="1292 324 1356 358">● 0</p>