

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000077	<ul style="list-style-type: none"> i Wyłącznik bezpieczeństwa i Microswitch 	● 2
	19001752	<ul style="list-style-type: none"> i Przełącznik zielony 4-pin i green switch 4-pin i grüner Umschalter 4-pin 	● 49
	19026967	<ul style="list-style-type: none"> i Grzałka 230V 1700W i Heater 230V 1700W 	● 0
	19027465	<ul style="list-style-type: none"> i Głowica grzewcza kompletna 400V i Complete heating head 400V 	● 1
	19027610	<ul style="list-style-type: none"> i Stycznik i Contactor 	● 0

Product image	SKU number	Product name	Available quantity
	19029841	<p data-bbox="657 264 1120 338">🇵🇱 Kosz kompletny 25x23x12cm do frytownicy</p> <p data-bbox="657 347 1120 421">🇬🇧 Complete basket 25x23x12 cm for electric fryer</p>	● 0