













- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19020007	<ul style="list-style-type: none">  Koszyk 20x22x10cm  Basket 20x22x10cm 	● 2
	19021611	<ul style="list-style-type: none">  Uchwyt dźwigni kranu ze śrubą  Tap lever handle with screw 	● 1
	19028080	<ul style="list-style-type: none">  Głowica grzewcza  Heating head 	● 2
	19028579	<ul style="list-style-type: none">  Rączka do koszyka do frytownicy  Fryer basket handle 	● 4