
















- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000137	<ul style="list-style-type: none">  Noodle Cooker Thermostat  Termostat WYE-110F 	● 0
	19004120	TIMER 120 RCPO-2000-1PE	● 14
	19004160	<ul style="list-style-type: none">  KOMIN  KAMIN  CHIMNEY RCRO 870 	● 3
	19004227	<ul style="list-style-type: none">  GRZAŁKA  Heizelemnt  Heater RCRO-1300 	● 0
	19004671	<ul style="list-style-type: none">  TERMOMETR  Thermometer RCRO-870 	● 0

Product image	SKU number	Product name	Available quantity
	19014462	<p>🇵🇱 Przewody do grzałki</p> <p>🇬🇧 Hoses to the heater</p>	● 0
	19021010	<p>🇵🇱 Zbiornik na popiół</p> <p>🇬🇧 Ash container</p>	● 7
	19021011	<p>🇵🇱 Drzwi z uszczelką</p> <p>🇬🇧 Door with seal</p>	● 0
	19023707	<p>🇵🇱 Moduł sterujący</p> <p>🇬🇧 Moduł sterujący</p>	● 2
	19028509	<p>🇵🇱 Wspornik grzałki- komplet</p> <p>🇬🇧 Complete Bracket for the food smoker's heating element</p>	● 0