

























- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19018575	<ul style="list-style-type: none"> i  Plastikowy zacisk  Bowl Cutter 	● 4
	19018743	<ul style="list-style-type: none"> i  Garnek  Pot 	● 0
	19018744	<ul style="list-style-type: none"> i  Ostrze  Knives 	● 0
	19022941	<ul style="list-style-type: none"> i  Silnik YS4-13890-2200W  Motor YS4-13890-2200W 	● 0
	19024673	<ul style="list-style-type: none"> i  Naklejka panelu sterowania z przyciskami  Control panel sticker with buttons 	● 3

Product image	SKU number	Product name	Available quantity
	19025259	<ul style="list-style-type: none">  Nóżka  Leg 	<ul style="list-style-type: none"> ● 10
	19028265	<ul style="list-style-type: none">  Plastikowy zatrzask pokrywy  Plastic cover latch 	<ul style="list-style-type: none"> ● 1
	19029914	<ul style="list-style-type: none">  Pokrywa kompletna do rozdrabniacza  Complete lid for bowl cutter 	<ul style="list-style-type: none"> ● 2