

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19014305</b>	 Wyłącznik bezpieczeństwa  Safety switch	<span style="color: green;">●</span> <b>3</b>
	<b>19014306</b>	 Włącznik  Power switch	<span style="color: green;">●</span> <b>1</b>
	<b>19014307</b>	 Łożysko  Bearing	<span style="color: green;">●</span> <b>3</b>
	<b>19014308</b>	 Łożysko  Bearing	<span style="color: green;">●</span> <b>3</b>
	<b>19014309</b>	 Łożysko UCFL  Bearing ucfl	<span style="color: green;">●</span> <b>3</b>

Product image	SKU number	Product name	Available quantity
	<b>19014310</b>	 Łańcuch  Chain	● 3
	<b>19014412</b>	 Wyłącznik awaryjny  Emergency stop button	● 5
	<b>19014413</b>	 Górna obudowa  Top cover	● 2
	<b>19019366</b>	 Pasek napędowy  Drive train	● 1
	<b>19019368</b>	 Mikro przełącznik  Micro switch	● 3
	<b>19019370</b>	 Naklejka panelu sterowania  Control panel sticker	● 12

Product image	SKU number	Product name	Available quantity
	<b>19019372</b>	<p>🇵🇱 Pokrętło</p> <p>🇬🇧 Adjusting knob of the support foot</p>	● 0
	<b>19023250</b>	<p>🇵🇱 Obudowa górna</p> <p>🇬🇧 Top housing</p>	● 2
	<b>19025737</b>	<p>🇵🇱 Moduł sterowania z włącznikiem</p> <p>🇬🇧 Control module with switch</p>	● 0
	<b>19029516</b>	<p>🇵🇱 Płyta główna-przetwornica częstotliwości</p> <p>🇬🇧 Main board-frequency converter</p>	● 0
	<b>19029517</b>	<p>🇵🇱 Płyta sterująca</p> <p>🇬🇧 Control board</p>	● 1
	<b>19029518</b>	<p>🇵🇱 Płyta zasilająca</p> <p>🇬🇧 Power supply PCB</p>	● 0