

















- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19015327	<ul style="list-style-type: none">  Uszczelka drzwi  Gasket 	● 2
	19015328	<ul style="list-style-type: none">  Osłona osi zawiasu drzwi  Door axis sheath 	● 2
	19015329	<ul style="list-style-type: none">  Oś zawiasu drzwi  Hinge axis 	● 2
	19015330	<ul style="list-style-type: none">  Czujnik  Sensor 	● 2
	19015331	<ul style="list-style-type: none">  Półka druciana  Shelf 	● 2

Product image	SKU number	Product name	Available quantity
	19015332	 Prowadnica półki lewa  Shelf guide-left	 0
	19015333	 Prowadnica półki prawa  Shelf guide-right	 0
	19025545	 Box 1 kompletny  Box 1 complete	 1
	19025549	 Box 2 kompletny  Box 2 complete	 0