













- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19015382	i Czujnik i Sensor	● 1
	19015383	i Blokada i lock	● 3
	19015384	i Wspornik regału siatkowego i Support of a net rack	● 1
	19015385	i Półka i Shelf	● 6
	19015386	i Półka dolna i Bottom shelf	● 1

Product image	SKU number	Product name	Available quantity
	19015387	 Oś zawiasu  Hinge axis	● 1
	19015388	 Osłona osi drzwi  Door axis sheath	● 1
	19015389	 Uszczelka  Gasket	● 0
	19017044	 Uchwyt drzwi  Door handle	● 6