













- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19015546	 Kosz na żywność  Food basket	 2
	19015547	 Kółka  Casters	 4
	19015548	 Listwa oświetleniowa  Light Bar	 0
	19015549	 Przełącznik  Switch	 2
	19015550	 Termostat  Thermostat	 1

Product image	SKU number	Product name	Available quantity
	19015551	 Transformator  Transformer	● 2
	19015552	 Sprężarka (wraz z wszystkimi akcesoriami)  Compressor(including all accessories)	● 2
	19015553	 Wentylator  Fan	● 2
	19027940	 Drzwi przesuwne lewe do zamrażarki  Left sliding door for a freezer	● 0