













- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19026143</b>	<ul style="list-style-type: none"> <li> Nóżka gumowa</li> <li> Rubber foot</li> </ul>	<span style="color: green;">●</span> <b>3</b>
	<b>19027039</b>	<ul style="list-style-type: none"> <li> Śruba krzyżakowa 2,5cm (do mocowania nóżki)</li> <li> Cross head screw 2,5cm (for mounting the foot)</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19027489</b>	<ul style="list-style-type: none"> <li> Grzałka 2200W</li> <li> Heater 2200W</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19029121</b>	<ul style="list-style-type: none"> <li> Obudowa dolna do grilla elektrycznego</li> <li> Bottom housing for electric griddle</li> </ul>	<span style="color: red;">●</span> <b>0</b>