













- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19026143	<p> Nóżka gumowa</p> <p> Rubber foot</p>	● 3
	19027039	<p> Śruba krzyżakowa 2,5cm (do mocowania nóżki)</p> <p> Cross head screw 2,5cm (for mounting the foot)</p>	● 0
	19027489	<p> Grzałka 2200W</p> <p> Heater 2200W</p>	● 0
	19029121	<p> Obudowa dolna do grilla elektrycznego</p> <p> Bottom housing for electric griddle</p>	● 0