




- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19016986	<p> Grzałka</p> <p> Heater</p>	● 0
	19016987	<p> Wyłącznik termiczny z wyłącznikiem silnika</p> <p> Thermal breaker with motor circuit breaker</p>	● 0
	19016988	<p> Przycisk - RESET</p> <p> RESET button</p>	● 1
	19025795	<p> Grzałka 220V~ 50Hz 800W [NOWY TYP]</p> <p> Heating element 220V~ 50Hz 800W [NEW TYPE]</p>	● 10
	19027634	<p> Filtr EMI VIP4-1A-03 do temperówki do czekolady</p> <p> EMI Filter VIP4-1A-03 for Chocolate Sharpener</p>	● 0

Product image	SKU number	Product name	Available quantity
	19029658	<ul style="list-style-type: none"> <li data-bbox="659 264 1062 338">🇵🇱 Elektroniczny regulator temperatury <li data-bbox="659 349 1062 423">🇬🇧 Electronic temperature controller 	<ul style="list-style-type: none"> <li data-bbox="1294 322 1358 356">● 0
	19029972	<ul style="list-style-type: none"> <li data-bbox="659 568 1010 642">🇵🇱 Plastikowe pokrętło prędkości silnika <li data-bbox="659 654 1094 687">🇬🇧 Motor speed plastic knob 	<ul style="list-style-type: none"> <li data-bbox="1294 607 1358 640">● 0
	19029973	<ul style="list-style-type: none"> <li data-bbox="659 860 1086 902">🇵🇱 Metalowy dysk mocujący <li data-bbox="659 913 1023 956">🇬🇧 Metal mounting disc 	<ul style="list-style-type: none"> <li data-bbox="1294 887 1358 920">● 0