




- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19016986	<ul style="list-style-type: none">  Grzałka  Heater 	● 0
	19016987	<ul style="list-style-type: none">  Wyłącznik termiczny z wyłącznikiem silnika  Thermal breaker with motor circuit breaker 	● 0
	19016988	<ul style="list-style-type: none">  Przycisk - RESET  RESET button 	● 1
	19025794	<ul style="list-style-type: none">  Grzałka 220V~ 50Hz 600W [NOWY TYP]  Heating element 220V~ 50Hz 600W [NEW TYPE] 	● 14
	19027634	<ul style="list-style-type: none">  Filtr EMI VIP4-1A-03 do temperówki do czekolady  EMI Filter VIP4-1A-03 for Chocolate Sharpener 	● 0

Product image	SKU number	Product name	Available quantity
	19028215	<p>🇵🇱 Plastikowa pokrywa z rączką</p> <p>🇬🇧 Plastic cover with handle</p>	● 0
	19029284	<p>🇵🇱 Wentylator osiowy 8x8x2,5 cm 220V 0,1A SF8025AT</p> <p>🇬🇧 Axial Fan 8x8x2.5 cm 220V 0.1A SF8025AT</p>	● 0
	19029929	<p>🇵🇱 Silnik elektryczny 5IK120A1-SF 120W 220V 0,75A 1250</p> <p>🇬🇧 1550r</p> <p>🇩🇪 min</p>	● 0