

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000604	<ul style="list-style-type: none">  Żarówka E27 60W  Bulb E27 60W 	● 7
	19001291	<ul style="list-style-type: none">  Szyba tylna 45x53 cm  Back glass 45x53 cm (for S04) 	● 7
	19001292	<ul style="list-style-type: none">  Szyba boczna 31x53 cm  Side glass 31x53 cm (for S04) 	● 2
	19002683	<ul style="list-style-type: none">  Szuflada 20x17 cm  Drawer 20x17 cm (for S04) 	● 0
	19017390	<ul style="list-style-type: none">  Drzwi szklane 36.5x21.5 cm [NOWY TYP]  Glass door 36.5x21.5 cm [NEW TYPE] (for S04) 	● 62

Product image	SKU number	Product name	Available quantity
	19026818	<p>🇵🇱 BOX 1 Kompletny</p> <p>🇬🇧 Complete BOX 1</p>	● 0
	19026819	<p>🇵🇱 BOX 2 Kompletny</p> <p>🇬🇧 Complete BOX 2</p>	● 1
	19027069	<p>🇵🇱 Włącznik 4 PIN</p> <p>🇬🇧 Switch 4 PIN</p>	● 3
	19027074	<p>🇵🇱 Garnek - wtyczka 5 PIN</p> <p>🇬🇧 Pot - 5 PIN plug</p>	● 0
	19029297	<p>🇵🇱 Obudowa dolna</p> <p>🇬🇧 Bottom housing for popcorn machine</p>	● 0
	19029602	<p>🇵🇱 Wspornik daszku przedni</p> <p>🇬🇧 Front roof support</p>	● 0

Product image	SKU number	Product name	Available quantity
	19029614	<ul style="list-style-type: none"> Wspornik daszku boczny z obudową (lewy prawy) Metal side roof support with housing (left	 0