

- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19018376</b>	<ul style="list-style-type: none"> <li> Mechanizm zamykania pokrywy</li> <li> Lid closing mechanism</li> </ul>	● 1
	<b>19018377</b>	<ul style="list-style-type: none"> <li> Pokrywa</li> <li> Kettle lid</li> </ul>	● 4
	<b>19018378</b>	<ul style="list-style-type: none"> <li> Przycisk pokrywy</li> <li> Lid button</li> </ul>	● 1
	<b>19018379</b>	<ul style="list-style-type: none"> <li> Podstawa pokrywy</li> <li> Bottom of the lid</li> </ul>	● 1
	<b>19018380</b>	<ul style="list-style-type: none"> <li> Przycisk otwierania</li> <li> Open button</li> </ul>	● 1

Product image	SKU number	Product name	Available quantity
	<b>19018381</b>	<p>  Osłona uchwyty   Handle cover </p>	<p>● <b>1</b></p>
	<b>19018382</b>	<p>  Podstawa czajnika   Kettle seat </p>	<p>● <b>1</b></p>
	<b>19024181</b>	<p>  Wyjmowana tacka [1]   Removable tray [1] </p>	<p>● <b>14</b></p>