expondo

SKU 10012718 Spare parts


List of available spare parts and related products

14/11/2026

Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.

The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19018367	Przycisk pokrywy Lid button	0
	19018368	Dekoracja pokrywy Pot lid decoration	0
	19018369	Pokrywa kompletna Complete lid	0
	19018370	Podstawa pokrywy Bottom of the lid	0
	19018371	Dekoracja podstawy pokrywy Decorative parts for the bottom of the lid	0

Product image	SKU number	Product name	Available quantity
	**19018372**	Obudowa Kettle housing	**1**
	**19018373**	Nóżka Foot pellet	**13**
	**19018374**	Podstawa czajnika Kettle seat	**1**
	**19018375**	Górna osłona uchwytu Handle cover	**2**
	**19022077**	Podstawa Base	**0**
	**19022078**	Pojemnik z przegródkami Container with dividers	**0**

Product image	SKU number	Product name	Available quantity
	**19022934**	Kratka ociekowa Drip grille	**2**
	**19028089**	Czajnik Electric kettle	**0**