

- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19019283	<ul style="list-style-type: none">  Element grzewczy  Heating element 	● 0
	19019285	<ul style="list-style-type: none">  Ogranicznik temperatury  Temperature limiter 	● 0
	19019286	<ul style="list-style-type: none">  Timer  Timer 	● 2
	19019287	<ul style="list-style-type: none">  Termostat  Thermostat 	● 6
	19019288	<ul style="list-style-type: none">  Pokrętło termostatu  Thermostat Knob 	● 0

Product image	SKU number	Product name	Available quantity
	19019291	<p>🇵🇱 Element grzejny</p> <p>🇬🇧 Heating element</p>	● 0
	19019292	<p>🇵🇱 Zespół drzwi</p> <p>🇬🇧 Door assembly</p>	● 1
	19019293	<p>🇵🇱 Kamień do pizzy</p> <p>🇬🇧 Pizza stone</p>	● 4
	19024264	<p>🇵🇱 Plastikowa nóżka regulowana</p> <p>🇬🇧 Plastic adjustable foot</p>	● 10
	19025390	<p>🇵🇱 Włącznik podwójny z podświetleniem</p> <p>🇬🇧 Double switch with backlight</p>	● 7
	19026118	<p>🇵🇱 Termobezpiecznik resetowalny KSD301R 250V 16A 130C</p> <p>🇬🇧 Resettable thermo-fuse KSD301R 250V 16A 130C</p>	● 3

Product image	SKU number	Product name	Available quantity
	19029350	 Szyba drzwi do pieca  Oven door glass	 0