























- i** Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i** The availability of the products may change.

| Product image | SKU number | Product name | Available quantity |
|--|-----------------|--|--------------------|
|  <p>GASTROPARTS</p> | 19001752 | <ul style="list-style-type: none">  Przełącznik zielony 4-pin  green switch 4-pin  grüner Umschalter 4-pin | 69 |
|  | 19021310 | <ul style="list-style-type: none">  Timer 5 min  Timer 5 mins | 1 |
|  | 19021311 | <ul style="list-style-type: none">  Żółty wskaźnik  Yellow indicator | 6 |
|  | 19021312 | <ul style="list-style-type: none">  Zielony wskaźnik  Green indicator | 7 |
|  | 19021313 | <ul style="list-style-type: none">  Pokrętło  Knob | 19 |

| Product image | SKU number | Product name | Available quantity |
|---|-----------------|---|--------------------|
|  | 19021314 | <p> Termostat 300?</p> <p> Thermostat 300?</p> | ● 0 |
|  | 19021325 | <p> Osłona kabla 10mm</p> <p> Cable head 10mm</p> | ● 6 |
|  | 19021326 | <p> Bezpiecznik termiczny 320oC</p> <p> TCO 320oC</p> | ● 4 |
|  | 19021327 | <p> Gumowe nóżki</p> <p> Rubber feet</p> | ● 28 |
|  | 19021329 | <p> Przełącznik</p> <p> Waterproof switch</p> | ● 0 |
|  | 19021330 | <p> BOX 1 kompletny</p> <p> BOX 1 complete</p> | ● 0 |

| Product image | SKU number | Product name | Available quantity |
|---|-----------------|---|--|
|  | 19021331 |  Przewód zasilający 3X1.5  Power cable 3X1.5 |  1 |