













- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19026473	<ul style="list-style-type: none">  Płyta główna BT-18F (V13)  Main board BT-18F (V13) 	● 4
	19027013	<ul style="list-style-type: none">  Cewka grzewcza do kuchni indukcyjnej  Heating coil for induction cooker 	● 2
	19027014	<ul style="list-style-type: none">  Szklana płyta robocza z obudową  Glass workplate with housing 	● 0
	19027781	<ul style="list-style-type: none">  Regulator mocy BT-I33  Power regulator BT-I33 	● 0