















- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19027036	<ul style="list-style-type: none">  Uchwyt plastikowy  Plastic handle 	● 12
	19028883	<ul style="list-style-type: none">  Kompletne drzwi do piekarnika  Complete oven door 	● 0
	19029443	<ul style="list-style-type: none">  Czujnik temperatury  Temperature sensor 	● 0
	19029444	<ul style="list-style-type: none">  Nóżka gwintowana  Threaded leg 	● 7
	19029567	<ul style="list-style-type: none">  Zawias dolny metalowy do piekarnika  Metal bottom hinge for oven 	● 2