

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19006462	<ul style="list-style-type: none">  Płyta CD z oprogramowaniem  CD-ROM with software  CD-Platte mit Software 	● 0
	19012613	<ul style="list-style-type: none">  Płytką sterującą wyświetlaczem  Control board 	● 0
	19014551	<ul style="list-style-type: none">  Panel przedni  Front panel 	● 1