








- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000313	SBS-LW-200A PAN STICKER	● 0
	19000365	<ul style="list-style-type: none"> 🇵🇱 SZALKA 🇬🇧 WIEGEPLATTE 🇩🇪 PLATE 	● 4
	19001269	<ul style="list-style-type: none"> 🇵🇱 PCB WITH DISPLAY 🇬🇧 Diaplaymodul 🇩🇪 moduł wyświetlacza do SBS-LW-200A 	● 0
	19001430	<ul style="list-style-type: none"> 🇵🇱 MODUŁ Z WYŚWIETLACZEM 🇬🇧 Modul mit Display 🇩🇪 Displaymodule do SBS-LW-200A 	● 3
	19001805	<ul style="list-style-type: none"> 🇵🇱 AKUMULATOR 🇬🇧 Akku 🇩🇪 battery 6V 2.8AH do SBS-LW-200A 	● 0

Product image	SKU number	Product name	Available quantity
	19001884	<p>🇵🇱 Czujnik tensometryczny</p> <p>🇬🇧 Load cell</p>	● 0
	19001885	<p>🇵🇱 ODWAŻNIK</p> <p>🇬🇧 Gewicht</p> <p>🇩🇪 weight 100G SBS-LW-200A</p>	● -4
	19001946	<p>🇵🇱 ZASILACZ 9v 500 mA</p> <p>🇬🇧 Netzteil</p> <p>🇩🇪 power supply</p>	● 0
	19002004	<p>🇵🇱 NÓŻKA</p> <p>🇬🇧 feet</p> <p>🇩🇪 Fuss DO WAGI SBS-LW-200A</p>	● 0
	19003576	<p>🇵🇱 ZASILACZ WEWNĘTRZNY</p> <p>🇬🇧 interne Stromversorgung</p> <p>🇩🇪 internal power supply SBS-LW-200A</p>	● 1
	19004603	<p>🇵🇱 OPAKOWANIE ZEWNĘTRZNE 42x41x31</p> <p>🇬🇧 Outer Packaging 42x41x31</p> <p>🇩🇪 Außenverpackung 42x41x31</p>	● 8

Product image	SKU number	Product name	Available quantity
	19008216	<p>  Opakowanie zastępcze 60x60x40 </p> <p>  substitute packaging 60x60x40 </p>	<p>● 118</p>
	19022668	<p>  Ściana boczna </p> <p>  Side wall </p>	<p>● 0</p>