expondo

SKU 10030069 Spare parts

15/11/2026


List of available spare parts and related products

Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.

The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	**19000354**	NEW MODULE FOR SBS-ZW-3001H Hauptplatine neu części zapasowe do wag	0
	**19000415**	DISPLAY BOARD FOR SBS-ZW-3001H MoDUŁ WYŚWIETLACZA Displaymodul	10
	**19000416**	KEYBOARD FOR SBS-ZW-3001H klawiatuta Tastatur	0
	**19000441**	BATTERY COVER (NEW) FOR SBS-ZW-3001 POKRYWA BATERII	16
	**19000523**	Szalka plastikowa plastic pan Schale aus Plastik	35

Product image	SKU number	Product name	Available quantity
	**19000575**	RUBBER PAD Gummibeleg für Schale FOR PAN SBS-PW-301C części zapasowe do wag	**0**
	**19000997**	AKUMULATOR 6V4AH BATTERY Akku	**35**
	**19001018**	SENSOR SENSOR SBS-ZW-3001H SENSOR SENSOR SBS-ZW-3001H	**18**
	**19001304**	OBUDOWA GÓRNA upper housing Obergehäuse for SBS-ZW-3001H	**8**
	**19001305**	OBUDOWA DOLNA lower housing Niedergehäuse for SBS-ZW-3001H	**19**
	**19001306**	Pokrywa szalki metalowa covers the metal pan Metalldeckel für die Wiegeplatte	**24**

Product image	SKU number	Product name	Available quantity
	**19001336**	PL ZASILACZ 9V300MA GB Adapter DE Netzteil	**3**
	**19001337**	PL NÓŻKA DO SBS-ZW-3001H GB Foot DE Fuss	**15**
	**19001380**	PL LIBELLA GB WASSERWAAGE DE LEVEL	**215**
	**19001686**	PL RAMA SZALKI GB frame pan DE Rahmen für die Wiegeplatte DO SBS-ZW-3001H	**11**
	**19001730**	PL AKUMULATOR 6V4AH GB Akku DE battery PRODUCENT	**0**
	**19001740**	PL PANEL PRZEDNI GB Vorderpanel DE Frontpanel DO SBS-ZW-3001H	**6**

Product image	SKU number	Product name	Available quantity
	**19001741**	PANEL KLAWIATURY Tastaturpanel Keyboard panel SBS-ZW-3001H	**0**
	**19003086**	POKRYWA BATERII NA 3 ŚRUBY Batteriefachdeckel für 3Schrauben battery cover for 3 screws SBS-ZW-3001H	**12**
	**19006929**	Opakowanie zewnętrzene 31,5x37,5x14,5 outside packaging 31,5x37,5x14,5 Außenverpackung 31,5x37,5x14,5	**0**
	**19008206**	Opakowanie zastępcze 40x40x20 substitute packaging 40x40x20	**39**
	**19011128**	Uszczelka gumowa Rubber gasket	**33**
	**19024779**	Plastikowa osłonka Plastic cover	**0**

Product image	SKU number	Product name	Available quantity
	**19027155**	Włącznik On off switch	**5**
	**19028045**	Gumowa uszczelka nóżki szalki Rubber seal for the pan leg	**0**