

- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	<b>19002883</b>	<ul style="list-style-type: none"> <li> Zasilacz 6V 500MA</li> <li> Netzteil6V 500MA</li> </ul>	<span style="color: red;">●</span> <b>0</b>
	<b>19002954</b>	<ul style="list-style-type: none"> <li> Nóżka SBS-PW-100</li> <li> 10</li> <li> Fuss</li> </ul>	<span style="color: green;">●</span> <b>3</b>
	<b>19002955</b>	<ul style="list-style-type: none"> <li> Szalka SBS-PW-100</li> <li> 10</li> <li> Schale</li> </ul>	<span style="color: green;">●</span> <b>3</b>
	<b>19003002</b>	<ul style="list-style-type: none"> <li> Podstawa szalki</li> <li> Schalebasis</li> <li> Panbase SBS-PW-100</li> </ul>	<span style="color: green;">●</span> <b>6</b>
	<b>19003004</b>	<ul style="list-style-type: none"> <li> Czujnik tensometryczny</li> <li> Wägezelle</li> <li> load cell SBS-PW-60</li> </ul>	<span style="color: red;">●</span> <b>0</b>

Product image	SKU number	Product name	Available quantity
	<b>19003005</b>	<p>🇵🇱 Płytką sterującą</p> <p>🇬🇧 Steuerplatine</p> <p>🇩🇪 Controlboard SBS-PW-60</p>	● 0
	<b>19003019</b>	<p>🇵🇱 SZALKKA</p> <p>🇬🇧 Wiegeplatte</p> <p>🇩🇪 pan SBS-PW-60</p>	● 1
	<b>19003172</b>	<p>🇵🇱 KRZYŻAK SZALKKI</p> <p>🇬🇧 Krezustück der Waagschale</p> <p>🇩🇪 cross for pan SBS-PW-60</p>	● 3
	<b>19003540</b>	<p>🇵🇱 WYŚWIETLACZ</p> <p>🇬🇧 ANZEIGE</p> <p>🇩🇪 DISPLAY SBS-PW-60</p>	● 14
	<b>19003675</b>	<p>🇵🇱 OPAKOWANIE ZEWNĘTRZNE 53x37x17</p> <p>🇬🇧 Outer Packaging 53x37x17</p> <p>🇩🇪 Außenverpackung 53x37x17 SBS-PW-60</p>	● 0
	<b>19003889</b>	<p>🇵🇱 AKUMULATOR 4V 6AH</p> <p>🇬🇧 Akku 4V 6AH</p> <p>🇩🇪 Battery 4V 6AH SBS-PW-60</p>	● 12

Product image	SKU number	Product name	Available quantity
	<b>19004010</b>	<p>🇵🇱 CZUJNIK TENSOMETRYCZNY</p> <p>🇬🇧 Wägezelle</p> <p>🇩🇪 sensor SBS-PW-60</p>	● 0
	<b>19004432</b>	<p>🇵🇱 KLAWIATURA</p> <p>🇬🇧 KEYBOARD</p> <p>🇩🇪 Tastatur SBS-PW-60</p>	● 3
	<b>19008213</b>	<p>🇵🇱 Opakowanie zastępcze 60x60x20</p> <p>🇬🇧 substitute packaging 60x60x20</p>	● 314
	<b>19009442</b>	<p>🇵🇱 Zestaw akcesoriów</p> <p>🇬🇧 Accessories set</p>	● 0
	<b>19014034</b>	<p>🇵🇱 Obudowa plastikowa dolna</p> <p>🇬🇧 Plastic bottom housing</p>	● 9
	<b>19018815</b>	<p>🇵🇱 Głowica kompletna</p> <p>🇬🇧 Head with display and buttons</p>	● 0