


- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19003712	<ul style="list-style-type: none">  Zasilacz 6V DC  1A  Netzteil 6V DC 	● 0
	19005006	<ul style="list-style-type: none">  PŁYTKA  PLATINE  BOARD SBS-PT-300C 	● 0
	19005620	<ul style="list-style-type: none">  ŚRUBA METALOWA Z PLASTIKOWĄ GŁOWĄ  Metallschraube mit Plastikkopf  metal screw with plastic head 	● 3
	19005846	<ul style="list-style-type: none">  Głowica SBS-PT-300C  head SBS-PT-300C  Kopf SBS-PT-300C 	● 0
	19005862	<ul style="list-style-type: none">  Opakowanie zewnętrzne 65x50x7  outside packaging 65x50x7  Außenverpackung 65x50x7 	● 4

Product image	SKU number	Product name	Available quantity
	19006122	<ul style="list-style-type: none">  Uchwyt metalowy czarny  black metal handle  schwarzer Metallgriff 	● 5
	19006352	<ul style="list-style-type: none">  pokrywa baterii plastikowa  plastic battery cover  Batteriefachdeckel aus Plastik 	● 2
	19006418	<ul style="list-style-type: none">  Nóżka  feet  Fuß 	● 4
	19006568	<ul style="list-style-type: none">  ZESTAW PŁYTEK PCB  PCB plates-set  PCB Platinen-Set 	● 3
	19007998	<ul style="list-style-type: none">  Opakowanie zewnętrzne 50x66x7  Outer packaging 50x66x7 	● 0
	19008109	<ul style="list-style-type: none">  Naklejka z opisem SBS-PT-300C  sticker with description SBS-PT-300C 	● 0

Product image	SKU number	Product name	Available quantity
	19008280	 AKUMULATOR 1.5V AA (4 szt.)  battery 1.5V AA (4 pieces)	● 0
	19009174	 Szybka wyświetlacza  Display glass	● 0