expondo

SKU 10030318 Spare parts



19/11/2026



List of available spare parts and related products

Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.

The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	**19001056**	NÓŻKA FUß FEET	**161**
	**19005370**	Zasilacz 6V 0,7A Adapter 6V 0,7A	**1**
	**19006769**	Podstawka szalki plastikowa z gumką stand plastic plate with a rubber band Plastikuntersetzer für Schale mit Gummi	**10**
	**19006771**	obudowa górna kompletna upper housing complete komplettes Obergehäuse	**9**
	19007517	Opakowanie zewnętrzne 14x33x40 outside packaging 14x33x40 Außenverpackung 14x33x40	**0**

Product image	SKU number	Product name	Available quantity
	**19007529**	Obudowa plastikowa dolna bottom plastic housing	**5**
	**19007530**	Szalka metalowa metal plat	**1**
	**19012755**	Bateria kwasowo-ołowiowa 4V 4Ah Lead-acid battery 4V 4Ah	**0**
	**19013223**	Naklejka wyświetlacza Display sticker	**0**
	**19013224**	Naklejka na klawiaturę Keyboard sticker	**0**
	**19013225**	Naklejka tylna Back sticker	**0**

Product image	SKU number	Product name	Available quantity
	**19013691**	Plastikowa nóżka Plastic leg	**3**
	**19019477**	Czujnik tensometryczny 40 kg Strain gauge sensor	**7**
	**19021122**	Przełącznik KCD1 6A 250V Switch KCD1 6A 250V	**1**