







- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19001056	<ul style="list-style-type: none">  NÓŻKA  FUß  FEET 	● 170
	19001722	<ul style="list-style-type: none">  AKUMULATOR 4V4AH PRODUCENTA KAF  Akku des KAF-Herstellers  battery KAF-supplier 	● 0
	19002030	<ul style="list-style-type: none">  SZALKA  Wiegeplatte  plate SBS-PW-302E 	● 5
	19007474	<ul style="list-style-type: none">  moduł sterujący KF FLA V2,3  control box KF FLA V2,3  Steuerungsmodul KF FLA V2,3 	● 0
	19007706	<ul style="list-style-type: none">  Zasilacz 6V 0,7A  Adapter 6V 0,7A 	● 0

Product image	SKU number	Product name	Available quantity
	19007862	<p>🇵🇱 Opakowanie zewnętrzne 38x15x38</p> <p>🇬🇧 outer packaging 38x15x38</p>	● 0
	19008623	<p>🇵🇱 Panel z nadrukiem</p> <p>🇬🇧 Panel with print</p>	● 3
	19008893	<p>🇵🇱 Obudowa dolna</p> <p>🇬🇧 Lower housing</p>	● 1
	19009572	<p>🇵🇱 Obudowa górna plastikowa</p> <p>🇬🇧 Upper plastic housing</p>	● 0
	19012030	<p>🇵🇱 Panel przedni</p> <p>🇬🇧 Front panel</p>	● 4
	19018447	<p>🇵🇱 Nóżka pod szalkę</p> <p>🇬🇧 Pan foot</p>	● 5