











- i Please review all available spare parts for this item, then contact us through the webform (found in the Help Centre in our website header). Let us know the SKU of each spare part you're interested in and the quantity you need.
- i The availability of the products may change.

Product image	SKU number	Product name	Available quantity
	19000997	<ul style="list-style-type: none">  AKUMULATOR 6V4AH  BATTERY  Akku 	● 1
	19023385	<ul style="list-style-type: none">  Płytką z wyświetlaczem HS1019  Display board HS1019 	● 0
	19023856	<ul style="list-style-type: none">  Zasilacz [Model:BX7W5-0800500E]  Power Adapter [Model:BX7W5-0800500E] 	● 22